

[ZPL WindowsCE SDK]

[Printer ZPL Command Development Manual v1.0]

1. Information of the Manual	4
2. Operation System	4
3. Remark.....	4
4. Method	5
4.1 PrinterCreator	5
4.2 PrinterCreatorS	6
4.3 PrinterDestroy.....	7
4.4 PortOpen.....	8
4.5 PortClose	10
4.6 WriteData	11
4.7 ReadData	12
4.8 DirectIO.....	13
4.9 ZPL_StartFormat	15
4.10 ZPL_EndFormat	16
4.11 ZPL_ScalableFontText.....	17
4.12 ZPL_Text.....	19
4.13 ZPL_BarCode39.....	21
4.14 ZPL_Pdf417.....	23
4.15 ZPL_CodeEan8	25
4.16 ZPL_UpceCode	27
4.17 ZPL_BarCode93.....	29
4.18 ZPL_BarCode128.....	31
4.19 ZPL_CodeEan13	33
4.20 ZPL_MicroPdf417.....	35
4.21 ZPL_QRCode	37
4.22 ZPL_UpcExtensions	39
4.23 ZPL_UpcaBarcode	41
4.24 ZPL_SetChangeFontEncoding	43
4.25 ZPL_SetChangeCaret	45
4.26 ZPL_SetChangeDelimiter.....	46
4.27 ZPL_SetChangeTilde	47
4.28 ZPL_GraphicBox.....	48
4.29 ZPL_GraphicCircle	50
4.30 ZPL_GraphicDiagonalLine	51
4.31 ZPL_GraphicEllipse	53
4.32 ZPL_PrintImage	55
4.33 ZPL_GraphicSymbol	56
4.34 ZPL_SetDiagnosticsMode	58
4.35 ZPL_SetLabelHome	59
4.36 ZPL_SetLabelLength.....	60
4.37 ZPL_SetLabelShift	61
4.38 ZPL_SetLabelTop	62
4.39 ZPL_SetPrintMode	63
4.40 ZPL_SetMediaType	64
4.41 ZPL_SetPrintingMirrorImage.....	65
4.42 ZPL_SetPrintOrientation	66
4.43 ZPL_SetPrintRate	67
4.44 ZPL_SetPrintWidth	68
4.45 ZPL_SetSerialCommunications.....	69
4.46 ZPL_SetPrintDarkness	71
4.47 ZPL_SetTearOffAdjustPosition.....	72
4.48 ZPL_PrintConfigurationLabel	73
4.49 ZPL_GetPrinterIpAddress	74
4.50 ZPL_GetPrinterStatus.....	75
4.51 ZPL_GetLabelLength.....	76
4.52 ZPL_GetLabelWidth	77

4.53 ZPL_GetPrinterSeriesNumber	78
4.54 ZPL_GetPrinterMacAddress	79
4.55 ZPL_GetPrinterName	80
4.56 ZPL_GetPrinterFirmwareVersion	81
4.57 ZPL_GetPrinterDpi	82
4.58 ZPL_LearnLabel.....	83
4.59 ZPL_SetReprintAfterError	84
4.60 ZPL_SetNetworkSetting.....	85
4.61 ZPL_SetMediaTracking	87

1. Information of the Manual

This SDK manual provides the dll file information for WinCE application development.

We continuously promote and update the function and quality of all our products. Any change to the product specification and the manual will be without any further notice.

2. Operation System

- WinCE 4.0/5.0/6.0
- Windows Mobile

3. Remark

- When error code Return Value is greater than 0, it is the internal error of Windows system, please refer to related help file.

4. Method

4.1 PrinterCreator

Set up the target printer of specified model (should create target printer before using any function).

```
int PrinterCreator(  
    void* handle,  
    const TCHAR* model  
)
```

Parameter:

```
void* handle  
    [in,out] The created target printer object.  
const TCHAR* model  
    [in] Specify the model of target printer.
```

Return Value:

Error Code	Value	Description
E_SUCCESS	0	Normal
E_NO_ENOUGMEMORY	-2	No enough memory
E_INVALID_MODEL	-8	Invalid model name

4.2 PrinterCreatorS

Set up the target printer of specified model, the function is same to PrinterCreator (should create target printer before using any function).

```
void* PrinterCreatorS(  
    const TCHAR* model  
)
```

Parameter:

const TCHAR model*
[in] Specify the model of target printer

Return:

Success : return the handle of printer object.

Fail: return NULL, invalid handle.

4.3 PrinterDestroy

Release the resource of specified model printer that has set up (after operation completed and no more operation for printer, it should release the printer that has set up).

```
int PrinterDestroy(  
    void* handle  
)
```

Parameter:

void handle*
[in] The handle of target printer object which needs to release.

Return Value:

Error Code	Value	Description
E_SUCCESS	0	Normal
E_BAD_HANDLE	-6	Invalid handle

4.4 PortOpen

Open the communication port and connect with the printer. After successfully connected, other functions can be used. If failed connecting, please check the error information.

```
int PortOpen(  
    void* handle,  
    const TCHAR* ioSettings  
)
```

Parameter:

```
void* handle  
    [in,out] The created target printer object.  
const TCHAR* ioSettings  
    [in] Set up the parameter of communication port that connected to the target  
        printer. Please see as below:
```

Configuration List:

Type	Configuration	Description	Sample
USB	USB[,Position/Model/PortNum]	USB: connect any USB printer of our company USB[,Position]: When connecting to multi printers of our company, can specify connecting to one particular USB printer through USB position information (Position parameter)	USB USB,Port_#0004.Hub_#0003 USB,LPG4 USB,USB001
NET	NET, IP Add (IPV4)[,Port]	Specify the IP add and port of internet printer. If not specifying port, the default port is 9100.	NET,192.168.0.36 NET,192.168.0.36,9100
COM	COMn,BAUDRATE_rate	Specify the number and baud rate of connected serial port .	COM5,BAUDRATE_19200
BSP	BSPn,BAUDRATE_rate	If you use WinCE device or Windows mobile, the specified port is BSPn, generally is BSP2.	BSP2,BAUDRATE_115200
BT	BT,Bluetooth address	Specify the Bluetooth address	BT, 8CDE52992EEF

Note: [] indicates selective parameter

Return Value:

Error Code	Value	Description
E_SUCCESS	0	Normal
E_INVALID_PARAMETER	-1	Invalid parameter
E_BAD_HANDLE	-6	Invalid handle
E_IO_PORT_OPEN_FAILED	-311	Port open failed

4.5 PortClose

This function is to close the communication port and disconnect with the printer.

```
int PortClose(  
    void* handle  
)
```

Parameter:

void handle*
[in,out] The created target printer object.

Return Value:

Error Code	Value	Description
E_SUCCESS	0	Normal
E_BAD_HANDLE	-6	Invalid handle

4.6 WriteData

This function is to send data to the printer.

```
int WriteData(  
    void* handle,  
    unsigned char* writeData,  
    unsigned int writeNum  
) ;
```

Parameter:

void handle*
[in,out] The created target printer object.
unsigned char writeData*
[in] The data sent to the printer (hex string).
unsigned int writeNum
[in] The length of the data sent.

Return Value:

Error Code	Value	Description
E_SUCCESS	0	Normal
E_BAD_HANDLE	-6	Invalid handle
E_IO_PORT_NOT_OPEN	-309	Communication port not open
E_IO_WRITE_FAILED	-321	Write failed
E_IO_WRITE_TIMEOUT	-322	Write timeout
E_IO_READ_FAILED	-331	Read failed
E_IO_READ_TIMEOUT	-332	Read timeout

4.7 ReadData

This function is to read the printer data.

```
int ReadData(  
    void* handle,  
    unsigned char* readData,  
    unsigned int readNum,  
    unsigned int* preadNum  
) ;
```

Parameter:

void handle*
[in,out] The created target printer object.
unsigned char readData*
[in] Printer data that needs to be read.
unsigned int readNum
[in] The length of data that needs to be read.
unsigned int preadNum*
[in] The length of the data actually read.

Return Value:

Error Code	Value	Description
E_SUCCESS	0	Normal
E_BAD_HANDLE	-6	Invalid handle
E_IO_PORT_NOT_OPEN	-309	Communication port not open
E_IO_READ_FAILED	-331	Read failed
E_IO_READ_TIMEOUT	-332	Read timeout

4.8 DirectIO

This function is for the user to customize the data sent and read by the printer. If some functions do not provide a function interface, the user can send command data to the printer through this interface.

```
int DirectIO(  
    void* handle,  
    unsigned char* writedata,  
    unsigned int writeNum,  
    unsigned char* readdata,  
    unsigned int readNum,  
    unsigned int* preaddedNum  
) ;
```

Parameter:

void handle*

[in,out] The created target printer object.

unsigned char writedata*

[in] The data written to the printer.

unsigned int writeNum

[in] The length of the data written to the printer.

When writeNum=0, the write data operation is not performed.

unsigned char readdata*

[in,out] Get the data returned by the printer.

unsigned int readNum

[in] Preset the length of data that needs to be read.

When readNum=0, the read data operation is not performed.

unsigned int preaddedNum*

[in,out] The length of the data actually read.

Return Value:

Error Code	Value	Description
E_SUCCESS	0	Normal
E_BAD_HANDLE	-6	Invalid handle
E_IO_PORT_NOT_OPEN	-309	Communication port not open
E_IO_WRITE_FAILED	-321	Write failed
E_IO_WRITE_TIMEOUT	-322	Write timeout
E_IO_READ_FAILED	-331	Read failed
E_IO_READ_TIMEOUT	-332	Read timeout

4.9 ZPL_StartFormat

This function is to indicate the beginning of a new label format.

```
int ZPL_StartFormat(  
    void* handle  
)
```

Parameter:

void handle*
[in,out] The created target printer object.

Return Value:

Error code	Value	Description
E_SUCCESS	0	Normal
E_INVALID_PARAMETER	-1	Invalid parameter
E_INVALID_MODEL_TYPE	-3	This model does not support this feature.
E_BAD_HANDLE	-6	Invalid handle
E_IO_PORT_NOT_OPEN	-309	Communication port not open
E_IO_WRITE_FAILED	-321	Write failed
E_IO_WRITE_TIMEOUT	-322	Write timeout

4.10 ZPL_EndFormat

This function is to indicate the end of a label format.

```
int ZPL_EndFormat(  
    void* handle  
)
```

Parameter:

void handle*
[in,out] The created target printer object.

Return Value:

Error code	Value	Description
E_SUCCESS	0	Normal
E_INVALID_PARAMETER	-1	Invalid parameter
E_INVALID_MODEL_TYPE	-3	This model does not support this feature.
E_BAD_HANDLE	-6	Invalid handle
E_IO_PORT_NOT_OPEN	-309	Communication port not open
E_IO_WRITE_FAILED	-321	Write failed
E_IO_WRITE_TIMEOUT	-322	Write timeout

4.11 ZPL_ScalableFontText

This function is to print scalable fonts.

```
int ZPL_ScalableFontText(  
    void* handle,  
    int xPos,  
    int yPos,  
    char fontName,  
    int orientation,  
    int fontWidth,  
    int fontHeight,  
    char* text  
) ;
```

Parameter:

```
void* handle  
    [in,out] The created target printer object.  
int xPos  
    [in] Horizontal starting position (range: 0-32000).  
int yPos  
    [in] Vertical starting position (range: 0-32000).  
char fontName  
    [in] Font(range: A-Z and 0-9).  
int orientation  
    [in] Print direction.  
        0 : normal  
        90 : Rotate 90 degrees clockwise  
        180: Rotate 180 degrees clockwise  
        270: Rotate 270 degrees clockwise
```

int fontWidth
 [in] Font width.
int fontHeight
 [in] Font height.
char text*
 [in]Text data.

Return Value:

Error code	Value	Description
E_SUCCESS	0	Normal
E_INVALID_PARAMETER	-1	Invalid parameter
E_INVALID_MODEL_TYPE	-3	This model does not support this feature.
E_BAD_HANDLE	-6	Invalid handle
E_IO_PORT_NOT_OPEN	-309	Communication port not open
E_IO_WRITE_FAILED	-321	Write failed
E_IO_WRITE_TIMEOUT	-322	Write timeout

4.12 ZPL_Text

This function is to print text.

```
int ZPL_Text(
```

```
    void* handle,
```

```
    int xPos,
```

```
    int yPos,
```

```
    int fontNum,
```

```
    int orientation,
```

```
    int fontWidth,
```

```
    int fontHeight,
```

```
    char* text
```

```
);
```

Parameter:

void handle*

[in,out] The created target printer object.

int xPos

[in] Horizontal starting position (range: 0-32000).

int yPos

[in] Vertical starting position (range: 0-32000).

int fontNum

[in] Font.

0 : FONT 0 -	Scalable font
1 : FONT A -	Bitmap font
2 : FONT B -	Bitmap font
3 : FONT D -	Bitmap font
4 : FONT E -	Bitmap font
5 : FONT F -	Bitmap font
6 : FONT G -	Bitmap font
7 : FONT H -	Bitmap font
8 : FONT GS -	Bitmap font
9 : FONT P -	Bitmap font
10 : FONT Q -	Bitmap font
11 : FONT R -	Bitmap font
12 : FONT S -	Bitmap font
13 : FONT T -	Bitmap font
14 : FONT U -	Bitmap font
15 : FONT V -	Bitmap font
16 : SIMSUN.TTF –	Song font

FONT A -- ABCDwxyz 12345
 FONT B -- ABCDWXYZ 12345 UPPER CASE ONLY
 FONT D -- ABCDwxyz 12345
 FONT E -- (OCR-B) ABCDwxyz 12345
 FONT F -- ABCDwxyz 12345
FONT G -- ABYz 12
 FONT H -- (OCR-A) UPPER CASE ONLY
 FONT O -- (Scaleable) ABCDwxyz 12345
 FONT GS -- ® ™ ®
 FONT P -- ABCDwxyz 12345
 FONT Q -- ABCDwxyz 12345
 FONT R -- ABCDwxyz 12345
 FONT S -- ABCDwxyz 12345
 FONT T -- ABCDwxyz 12345
 FONT U -- ABCDwxyz 12345
FONT V -- ABCDwxyz 12345

int orientation

[in] Print direction.

0 : normal
90: Rotate 90 degrees clockwise
180: Rotate 180 degrees clockwise
270: Rotate 270 degrees clockwise

int fontWidth

[in] Font width.

int fontHeight

[in] Font height.

char text*

[in]Text data.

Return Value:

Error code	Value	Description
E_SUCCESS	0	Normal
E_INVALID_PARAMETER	-1	Invalid parameter
E_INVALID_MODEL_TYPE	-3	This model does not support this feature.
E_BAD_HANDLE	-6	Invalid handle
E_IO_PORT_NOT_OPEN	-309	Communication port not open
E_IO_WRITE_FAILED	-321	Write failed
E_IO_WRITE_TIMEOUT	-322	Write timeout

4.13 ZPL_BarCode39

This function is to print Barcode39 barcodes.

```
int ZPL_BarCode39(
```

```
    void* handle,
```

```
    int xPos,
```

```
    int yPos,
```

```
    int orientation,
```

```
    int moduleWidth,
```

```
    int codeHeight,
```

```
    char line,
```

```
    char lineAboveCode,
```

```
    char digit,
```

```
    char* text
```

```
);
```

Parameter:

```
void* handle
```

[in,out] The created target printer object.

```
int xPos
```

[in] Horizontal starting position (range: 0-32000).

```
int yPos
```

[in] Vertical starting position (range: 0-32000).

```
int orientation
```

[in] Print direction.

0 : normal

90 : Rotate 90 degrees clockwise

180: Rotate 180 degrees clockwise

270: Rotate 270 degrees clockwise

```

int moduleWidth
    [in] Bar code width (range: 0-10).
int codeHeight
    [in] Bar code height.
char line
    [in] Comment line.
    'N': not print
    'Y': print
char lineAboveCode
    [in] The comment line above the barcode.
    'N': not print above the barcode
    'Y': print above the barcode
char digit
    [in] Check Digit.
    'N': do not print check digit
    'Y': print check digit
char* text
    [in] Text data.

```

Return Value:

Error code	Value	Description
E_SUCCESS	0	Normal
E_INVALID_PARAMETER	-1	Invalid parameter
E_INVALID_MODEL_TYPE	-3	This model does not support this feature.
E_BAD_HANDLE	-6	Invalid handle
E_IO_PORT_NOT_OPEN	-309	Communication port not open
E_IO_WRITE_FAILED	-321	Write failed
E_IO_WRITE_TIMEOUT	-322	Write timeout

4.14 ZPL_Pdf417

This function is to print the Pdf417 code.

```
int ZPL_Pdf417(  
    void* handle,  
    int xPos,  
    int yPos,  
    int orientation,  
    int moduleWidth,  
    int codeHeight,  
    int securityLevel,  
    int column,  
    int rows,  
    char truncate,  
    char* text  
);
```

Parameter:

```
void* handle  
    [in,out]The created target printer object.  
int xPos  
    [in] Horizontal starting position (range: 0-32000).  
int yPos  
    [in] Vertical starting position (range: 0-32000).
```

int orientation

[in] Print direction.

0 : normal

90: Rotate 90 degrees clockwise

180: Rotate 180 degrees clockwise

270: Rotate 270 degrees clockwise

int moduleWidth

[in] Bar code width (range: 0-10).

int codeHeight

[in] Bar code height.

int securityLevel

[in] Security level (range:1-8).

int column

[in] The number of columns to encode.

int rows

[in] The number of rows to encode.

char truncate

[in] Truncated layer indication and stop mode.

'N': not truncated

'Y': execution truncation

char text*

[in] QR code data.

Return value:

Error code	Value	Description
E_SUCCESS	0	Normal
E_INVALID_PARAMETER	-1	Invalid parameter
E_INVALID_MODEL_TYPE	-3	This model does not support this feature.
E_BAD_HANDLE	-6	Invalid handle
E_IO_PORT_NOT_OPEN	-309	Communication port not open
E_IO_WRITE_FAILED	-321	Write failed
E_IO_WRITE_TIMEOUT	-322	Write timeout

4.15 ZPL_CodeEan8

This function is to print CodeEan8 barcodes.

```
int ZPL_CodeEan8(  
    void* handle,  
    int xPos,  
    int yPos,  
    int orientation,  
    int moduleWidth,  
    int codeHeight,  
    char line,  
    char lineAboveCode,  
    char* text  
);
```

Parameter:

```
void* handle  
    [in,out]The created target printer object.  
int xPos  
    [in] Horizontal starting position (range: 0-32000).  
int yPos  
    [in] Vertical starting position (range: 0-32000).  
int orientation  
    [in] Print direction.  
        0 : normal  
        90 : Rotate 90 degrees clockwise  
        180: Rotate 180 degrees clockwise  
        270: Rotate 270 degrees clockwise  
int moduleWidth  
    [in] Bar code width (range: 0-10).
```

```

int codeHeight
    [in] Bar code height.
char line
    [in] Comment line.
    'N': not print
    'Y': print
char lineAboveCode
    [in] The comment line above the barcode.
    'N': not print above the barcode
    'Y': print above the barcode
char* text
    [in] Text data.

```

Return Value:

Error code	Value	Description
E_SUCCESS	0	Normal
E_INVALID_PARAMETER	-1	Invalid parameter
E_INVALID_MODEL_TYPE	-3	This model does not support this feature.
E_BAD_HANDLE	-6	Invalid handle
E_IO_PORT_NOT_OPEN	-309	Communication port not open
E_IO_WRITE_FAILED	-321	Write failed
E_IO_WRITE_TIMEOUT	-322	Write timeout

4.16 ZPL_UpceCode

This function is to print UPC-E barcodes.

```
int ZPL_UpceCode(  
    void* handle,  
    int xPos,  
    int yPos,  
    int orientation,  
    int moduleWidth,  
    int codeHeight,  
    char line,  
    char lineAboveCode,  
    char* text  
);
```

Parameter:

```
void* handle  
    [in,out]The created target printer object.  
int xPos  
    [in] Horizontal starting position (range: 0-32000).  
int yPos  
    [in] Vertical starting position (range: 0-32000).  
int orientation  
    [in] Print direction.  
        0 : normal  
        90 : Rotate 90 degrees clockwise  
        180: Rotate 180 degrees clockwise  
        270: Rotate 270 degrees clockwise
```

int moduleWidth
 [in] Bar code width (range: 0-10).
int codeHeight
 [in] Bar code height.
char line
 [in] Comment line.
 'N': not print
 'Y': print
char lineAboveCode
 [in] The comment line above the barcode.
 'N': not print above the barcode
 'Y': print above the barcode
char text*
 [in] Text data.

Return Value:

Error code	Value	Description
E_SUCCESS	0	Normal
E_INVALID_PARAMETER	-1	Invalid parameter
E_INVALID_MODEL_TYPE	-3	This model does not support this feature.
E_BAD_HANDLE	-6	Invalid handle
E_IO_PORT_NOT_OPEN	-309	Communication port not open
E_IO_WRITE_FAILED	-321	Write failed
E_IO_WRITE_TIMEOUT	-322	Write timeout

4.17 ZPL_BarCode93

This function is to print Barcode93 barcodes.

```
int ZPL_BarCode93(  
    void* handle,  
    int xPos,  
    int yPos,  
    int orientation,  
    int moduleWidth,  
    int codeHeight,  
    char line,  
    char lineAboveCode,  
    char digit,  
    char* text  
);
```

Parameter:

```
void* handle  
    [in,out] The created target printer object.  
int xPos  
    [in] Horizontal starting position (range: 0-32000).  
int yPos  
    [in] Vertical starting position (range: 0-32000).  
int orientation  
    [in] Print direction.  
        0 : normal  
        90 : Rotate 90 degrees clockwise  
        180: Rotate 180 degrees clockwise  
        270: Rotate 270 degrees clockwise
```

```

int moduleWidth
    [in] Bar code width (range: 0-10).
int codeHeight
    [in] Bar code height.
char line
    [in] Comment line.
    'N': not print
    'Y': print
char lineAboveCode
    [in] The comment line above the barcode.
    'N': not print above the barcode
    'Y': print above the barcode
char digit
    [in] Check Digit.
    'N': do not print check digit
    'Y': print check digit
char* text
    [in] Text data.

```

Return Value:

Error code	Value	Description
E_SUCCESS	0	Normal
E_INVALID_PARAMETER	-1	Invalid parameter
E_INVALID_MODEL_TYPE	-3	This model does not support this feature.
E_BAD_HANDLE	-6	Invalid handle
E_IO_PORT_NOT_OPEN	-309	Communication port not open
E_IO_WRITE_FAILED	-321	Write failed
E_IO_WRITE_TIMEOUT	-322	Write timeout

4.18 ZPL_BarCode128

This function is to print Barcode128 barcodes.

```
int ZPL_BarCode128(  
    void* handle,  
    int xPos,  
    int yPos,  
    int orientation,  
    int moduleWidth,  
    int codeHeight,  
    char line,  
    char lineAboveCode,  
    char checkDigit,  
    char mode,  
    char* text  
) ;
```

Parameter:

```
void* handle  
    [in,out] The created target printer object.  
int xPos  
    [in] Horizontal starting position (range: 0-32000).  
int yPos  
    [in] Vertical starting position (range: 0-32000).
```

int orientation
[in] Print direction.
0 : normal
90: Rotate 90 degrees clockwise
180: Rotate 180 degrees clockwise
270: Rotate 270 degrees clockwise

int moduleWidth
[in] Bar code width (range: 0-10).

int codeHeight
[in] Bar code height.

char line
[in] Comment line.
'N': not print
'Y': print

char lineAboveCode
[in] The comment line above the barcode.
'N': not print above the barcode
'Y': print above the barcode

char checkDigit
[in] UCC check Digit.
'N': do not print check digit
'Y': print check digit

char mode
[in] Mode.
'N': no choice mode
'U': UCC matching mode
'A': automatic mode
'D': UCC/EAN mode

char text*
[in] Text data.

Return Value:

Error code	Value	Description
E_SUCCESS	0	Normal
E_INVALID_PARAMETER	-1	Invalid parameter
E_INVALID_MODEL_TYPE	-3	This model does not support this feature.
E_BAD_HANDLE	-6	Invalid handle
E_IO_PORT_NOT_OPEN	-309	Communication port not open
E_IO_WRITE_FAILED	-321	Write failed
E_IO_WRITE_TIMEOUT	-322	Write timeout

4.19 ZPL_CodeEan13

This function is to print CodeEan13 barcodes.

```
int ZPL_CodeEan13(  
    void* handle,  
    int xPos,  
    int yPos,  
    int orientation,  
    int moduleWidth,  
    int codeHeight,  
    char line,  
    char lineAboveCode,  
    char* text  
);
```

Parameter:

```
void* handle  
    [in,out]The created target printer object.  
int xPos  
    [in] Horizontal starting position (range: 0-32000).  
int yPos  
    [in] Vertical starting position (range: 0-32000).  
int orientation  
    [in] Print direction.  
        0 : normal  
        90: Rotate 90 degrees clockwise  
        180: Rotate 180 degrees clockwise  
        270: Rotate 270 degrees clockwise
```

int moduleWidth
 [in] Bar code width (range: 0-10).
int codeHeight
 [in] Bar code height.
char line
 [in] Comment line.
 'N': not print
 'Y': print
char lineAboveCode
 [in] The comment line above the barcode.
 'N': not print above the barcode
 'Y': print above the barcode
char text*
 [in] Text data.

Return Value:

Error code	Value	Description
E_SUCCESS	0	Normal
E_INVALID_PARAMETER	-1	Invalid parameter
E_INVALID_MODEL_TYPE	-3	This model does not support this feature.
E_BAD_HANDLE	-6	Invalid handle
E_IO_PORT_NOT_OPEN	-309	Communication port not open
E_IO_WRITE_FAILED	-321	Write failed
E_IO_WRITE_TIMEOUT	-322	Write timeout

4.20 ZPL_MicroPdf417

This function is to print MicroPdf417 codes.

```
int ZPL_MicroPdf417(  
    void* handle,  
    int xPos,  
    int yPos,  
    int orientation,  
    int moduleWidth,  
    int codeHeight,  
    int mode,  
    char* text  
) ;
```

Parameter:

```
void* handle  
    [in,out]The created target printer object.  
int xPos  
    [in] Horizontal starting position (range: 0-32000).  
int yPos  
    [in] Vertical starting position (range: 0-32000).  
int orientation  
    [in] Print direction.  
        0 : normal  
        90 : Rotate 90 degrees clockwise  
        180: Rotate 180 degrees clockwise  
        270: Rotate 270 degrees clockwise  
  
int moduleWidth  
    [in] Bar code width (range: 0-10).  
int codeHeight  
    [in] Bar code height.
```

int mode

[in] Mode(range: 0-33).

Mode (M)	Number of Data Columns	Number of Data Rows	% of Cws for EC	Max Alpha Characters	Max Digits
0	1	11	64	6	8
1	1	14	50	12	17
2	1	17	41	18	26
3	1	20	40	22	32
4	1	24	33	30	44
5	1	28	29	38	55
6	2	8	50	14	20
7	2	11	41	24	35
8	2	14	32	36	52
9	2	17	29	46	67
10	2	20	28	56	82
11	2	23	28	64	93
12	2	26	29	72	105
13	3	6	67	10	14
14	3	8	58	18	26
15	3	10	53	26	38
16	3	12	50	34	49
17	3	15	47	46	67
18	3	20	43	66	96
19	3	26	41	90	132
20	3	32	40	114	167
21	3	38	39	138	202
22	3	44	38	162	237
23	4	6	50	22	32
24	4	8	44	34	49
25	4	10	40	46	67
26	4	12	38	58	85
27	4	15	35	76	111
28	4	20	33	106	155
29	4	26	31	142	208
30	4	32	30	178	261
31	4	38	29	214	313
32	4	44	28	250	366
33	4	4	50	14	20

char text*

[in] Text data.

Return Value:

Error code	Value	Description
E_SUCCESS	0	Normal
E_INVALID_PARAMETER	-1	Invalid parameter
E_INVALID_MODEL_TYPE	-3	This model does not support this feature.
E_BAD_HANDLE	-6	Invalid handle
E_IO_PORT_NOT_OPEN	-309	Communication port not open
E_IO_WRITE_FAILED	-321	Write failed
E_IO_WRITE_TIMEOUT	-322	Write timeout

4.21 ZPL_QRCode

This function is to print a QR code.

```
int ZPL_QRCode(  
    void* handle,  
    int xPos,  
    int yPos,  
    int orientation,  
    int model,  
    int dpi,  
    char eccLevel,  
    int maskMode,  
    char* text  
) ;
```

Parameter:

void handle*

[in,out] The created target printer object.

int xPos

[in] Horizontal starting position (range: 0-32000).

int yPos

[in] Vertical starting position (range: 0-32000).

int orientation

[in] Print direction.

0 : normal

90 : Rotate 90 degrees clockwise

180: Rotate 180 degrees clockwise

270: Rotate 270 degrees clockwise

int model

[in] Set the QR code version (1: original version, 2: enhanced version).

int dpi
[in] Magnification factor (range: 1-10).

char eccLevel
[in] Error correction level.
H: Ultra high reliability
Q: High reliability
M: standard level
L: high density level

int maskMode
[in] Mask mode (range: 0-7).

char text*
[in] QR code data.

Return Value:

Error code	Value	Description
E_SUCCESS	0	Normal
E_INVALID_PARAMETER	-1	Invalid parameter
E_INVALID_MODEL_TYPE	-3	This model does not support this feature.
E_BAD_HANDLE	-6	Invalid handle
E_IO_PORT_NOT_OPEN	-309	Communication port not open
E_IO_WRITE_FAILED	-321	Write failed
E_IO_WRITE_TIMEOUT	-322	Write timeout

4.22 ZPL_UpcExtensions

This function is to print UPC extended barcodes.

```
int ZPL_UpcExtensions(  
    void* handle,  
    int xPos,  
    int yPos,  
    int orientation,  
    int moduleWidth,  
    int codeHeight,  
    char line,  
    char lineAboveCode,  
    char* text  
);
```

Parameter:

```
void* handle  
    [in,out]The created target printer object.  
int xPos  
    [in] Horizontal starting position (range: 0-32000).  
int yPos  
    [in] Vertical starting position (range: 0-32000).  
int orientation  
    [in] Print direction.  
        0 : normal  
        90 : Rotate 90 degrees clockwise  
        180: Rotate 180 degrees clockwise  
        270: Rotate 270 degrees clockwise
```

int moduleWidth
 [in] Bar code width (range: 0-10).

int codeHeight
 [in] Bar code height.

char line
 [in] Comment line.
 'N': not print
 'Y': print

char lineAboveCode
 [in] The comment line above the barcode.
 'N': not print above the barcode
 'Y': print above the barcode

char text*
 [in] Text data.

Return Value:

Error code	Value	Description
E_SUCCESS	0	Normal
E_INVALID_PARAMETER	-1	Invalid parameter
E_INVALID_MODEL_TYPE	-3	This model does not support this feature.
E_BAD_HANDLE	-6	Invalid handle
E_IO_PORT_NOT_OPEN	-309	Communication port not open
E_IO_WRITE_FAILED	-321	Write failed
E_IO_WRITE_TIMEOUT	-322	Write timeout

4.23 ZPL_UpcaBarcode

This function is to print UPC-A barcodes.

```
int ZPL_UpcaBarcode(
```

```
    void* handle,  
    int xPos,  
    int yPos,  
    int orientation,  
    int moduleWidth,  
    int codeHeight,  
    char line,  
    char lineAboveCode,  
    char digit,  
    char* text
```

```
);
```

Parameter:

```
void* handle  
    [in,out] The created target printer object.  
int xPos  
    [in] Horizontal starting position (range: 0-32000).  
int yPos  
    [in] Vertical starting position (range: 0-32000).  
int orientation
```

```
    [in] Print direction.  
        0 : normal  
        90 : Rotate 90 degrees clockwise  
        180: Rotate 180 degrees clockwise  
        270: Rotate 270 degrees clockwise
```

```

int moduleWidth
    [in] Bar code width (range: 0-10).
int codeHeight
    [in] Bar code height.
char line
    [in] Comment line.
    'N': not print
    'Y': print
char lineAboveCode
    [in] The comment line above the barcode.
    'N': not print above the barcode
    'Y': print above the barcode
char digit
    [in] Check Digit.
    'N': do not print check digit
    'Y': print check digit
char* text
    [in] Text data.

```

Return Value:

Error code	Value	Description
E_SUCCESS	0	Normal
E_INVALID_PARAMETER	-1	Invalid parameter
E_INVALID_MODEL_TYPE	-3	This model does not support this feature.
E_BAD_HANDLE	-6	Invalid handle
E_IO_PORT_NOT_OPEN	-309	Communication port not open
E_IO_WRITE_FAILED	-321	Write failed
E_IO_WRITE_TIMEOUT	-322	Write timeout

4.24 ZPL_SetChangeFontEncoding

This function is to select an international character set.

```
int ZPL_SetChangeFontEncoding(  
    void* handle,  
    int encodeType  
) ;
```

Parameter:

```
void* handle  
    [in,out] The created target printer object.  
int encodeType  
    [in] Character set type (range: 0-31, 33-36).  
        0 : single byte encoding - US 1 character set  
        1 : Single-byte encoding - US 2 character set  
        2 : Single Byte Encoding - British Character Set  
        3 : Single Byte Encoding - Dutch Character Set  
        4 : Single-byte encoding - Danish/Norwegian character set  
        5 : Single-byte encoding - Swedish/Finnish character set  
        6 : Single byte encoding - German character set  
        7 : Single-byte encoding - French 1 character set  
        8 : Single-byte encoding - French 2 character set  
        9 : Single-byte encoding - Italian character set  
       10 : Single Byte Encoding - Spanish Character Set  
       11 : Single Byte Encoding - Miscellaneous Character Set  
       12 : Single-byte encoding - Japanese character set  
       13 : Zebra Code Page 850  
       14 : Double Byte Asian Code  
       15 : Shift-JIS  
       16 : EUC-JP and EUC-CN  
       17 : Not recommended - UCS-2 BigEndian  
       18-23 : Reserved  
       24 : Single Byte Asian Code  
       25 : Reserved  
       26 : Multibyte Asian Code
```

- 27 : Zebra Code Page 1252
- 28 : Unicode (UTF-8 encoding) - Unicode character set
- 29 : Unicode (UTF-16 Big-Endian encoding) - Unicode character set
- 30 : Unicode (UTF-16 Little-Endian encoding) - Unicode character set
- 31 : Zebra Code Page 1250
- 33 : Code page 1251
- 34 : Code page 1253
- 35 : Code page 1254
- 36 : Code page 1255

Return Value:

Error code	Value	Description
E_SUCCESS	0	Normal
E_INVALID_PARAMETER	-1	Invalid parameter
E_INVALID_MODEL_TYPE	-3	This model does not support this feature.
E_BAD_HANDLE	-6	Invalid handle
E_IO_PORT_NOT_OPEN	-309	Communication port not open
E_IO_WRITE_FAILED	-321	Write failed
E_IO_WRITE_TIMEOUT	-322	Write timeout

4.25 ZPL_SetChangeCaret

This function is to change the format command prefix.

```
int ZPL_SetChangeCaret(  
    void* handle,  
    char character  
) ;
```

Parameter:

void handle*
[in,out] The created target printer object.
char character
[in] Format command prefix.

Return Value:

Error code	Value	Description
E_SUCCESS	0	Normal
E_INVALID_PARAMETER	-1	Invalid parameter
E_INVALID_MODEL_TYPE	-3	This model does not support this feature.
E_BAD_HANDLE	-6	Invalid handle
E_IO_PORT_NOT_OPEN	-309	Communication port not open
E_IO_WRITE_FAILED	-321	Write failed
E_IO_WRITE_TIMEOUT	-322	Write timeout

4.26 ZPL_SetChangeDelimiter

This function is to change the separator.

```
int ZPL_SetChangeDelimiter(  
    void* handle,  
    char character  
) ;
```

Parameter:

void handle*
[in,out] The created target printer object.
char character
[in] Separator.

Return Value:

Error code	Value	Description
E_SUCCESS	0	Normal
E_INVALID_PARAMETER	-1	Invalid parameter
E_INVALID_MODEL_TYPE	-3	This model does not support this feature.
E_BAD_HANDLE	-6	Invalid handle
E_IO_PORT_NOT_OPEN	-309	Communication port not open
E_IO_WRITE_FAILED	-321	Write failed
E_IO_WRITE_TIMEOUT	-322	Write timeout

4.27 ZPL_SetChangeTilde

This function is to change the control command prefix.

```
int ZPL_SetChangeTilde(  
    void* handle,  
    char character  
) ;
```

Parameter:

void handle*
[in,out] The created target printer object.
char character
[in] Control command prefix.

Return Value:

Error code	Value	Description
E_SUCCESS	0	Normal
E_INVALID_PARAMETER	-1	Invalid parameter
E_INVALID_MODEL_TYPE	-3	This model does not support this feature.
E_BAD_HANDLE	-6	Invalid handle
E_IO_PORT_NOT_OPEN	-309	Communication port not open
E_IO_WRITE_FAILED	-321	Write failed
E_IO_WRITE_TIMEOUT	-322	Write timeout

4.28 ZPL_GraphicBox

This function is to draw a graphic box.

```
int ZPL_GraphicBox(  
    void* handle,  
    int xPos,  
    int yPos,  
    int width,  
    int height,  
    int thickness,  
    int rounding,  
) ;
```

Parameter:

```
void* handle  
    [in,out] The created target printer object.  
int xPos  
    [in] Horizontal starting position (range: 0-32000).  
int yPos  
    [in] Vertical starting position (range: 0-32000).  
int width  
    [in] The width of the box (range: 1-32000, unit: dot).  
int height  
    [in] The height of the box (range: 1-32000, unit: dot).  
int thickness  
    [in] Boundary thickness (range: 1-32000, unit: dot).  
int rounding  
    [in] Degree of rotation (range: 0-8).
```

Return Value:

Error code	Value	Description
E_SUCCESS	0	Normal
E_INVALID_PARAMETER	-1	Invalid parameter
E_INVALID_MODEL_TYPE	-3	This model does not support this feature.
E_BAD_HANDLE	-6	Invalid handle
E_IO_PORT_NOT_OPEN	-309	Communication port not open
E_IO_WRITE_FAILED	-321	Write failed
E_IO_WRITE_TIMEOUT	-322	Write timeout

4.29 ZPL_GraphicCircle

This function is to draw a graphic circle.

```
int ZPL_GraphicCircle(  
    void* handle,  
    int xPos,  
    int yPos,  
    int diameter,  
    int thickness,  
) ;
```

Parameter:

```
void* handle  
    [in,out] The created target printer object.  
int xPos  
    [in] Horizontal starting position (range: 0-32000).  
int yPos  
    [in] Vertical starting position (range: 0-32000).  
int diameter  
    [in] Round diameter(range:3-4095).  
int thickness  
    [in] Boundary thickness(range:1-4095).
```

Return Value:

Error code	Value	Description
E_SUCCESS	0	Normal
E_INVALID_PARAMETER	-1	Invalid parameter
E_INVALID_MODEL_TYPE	-3	This model does not support this feature.
E_BAD_HANDLE	-6	Invalid handle
E_IO_PORT_NOT_OPEN	-309	Communication port not open
E_IO_WRITE_FAILED	-321	Write failed
E_IO_WRITE_TIMEOUT	-322	Write timeout

4.30 ZPL_GraphicDiagonalLine

This function is to draw diagonals.

```
int ZPL_GraphicDiagonalLine(  
    void* handle,  
    int xPos,  
    int yPos,  
    int orientation,  
    int width,  
    int height,  
    int thickness  
) ;
```

Parameter:

```
void* handle  
    [in,out] The created target printer object.  
int xPos  
    [in] Horizontal starting position (range: 0-32000).  
int yPos  
    [in] Vertical starting position (range: 0-32000).  
int orientation  
    [in] The direction of the diagonal.  
        R (/) : right slanted diagonal  
        L (\) : left slanted diagonal  
int width  
    [in] The width of the box (range: 1-32000, unit: dot).  
int height  
    [in] The height of the box (range: 1-32000, unit: dot).  
int thickness  
    [in] Boundary thickness (range: 1-32000, unit: dot).
```

Return Value:

Error code	Value	Description
E_SUCCESS	0	Normal
E_INVALID_PARAMETER	-1	Invalid parameter
E_INVALID_MODEL_TYPE	-3	This model does not support this feature.
E_BAD_HANDLE	-6	Invalid handle
E_IO_PORT_NOT_OPEN	-309	Communication port not open
E_IO_WRITE_FAILED	-321	Write failed
E_IO_WRITE_TIMEOUT	-322	Write timeout

4.31 ZPL_GraphicEllipse

This function is to draw a graphical ellipse.

```
int ZPL_GraphicEllipse(  
    void* handle,  
    int xPos,  
    int yPos,  
    int width,  
    int height,  
    int thickness  
) ;
```

Parameter:

```
void* handle  
    [in,out] The created target printer object.  
int xPos  
    [in] Horizontal starting position (range: 0-32000).  
int yPos  
    [in] Vertical starting position (range: 0-32000).  
int width  
    [in] Ellipse width (range: 3-4095, unit: dot).  
int height  
    [in] Ellipse height (range: 3-4095, unit: dot).  
int thickness  
    [in] Boundary thickness (range: 2-4095, unit: dot).
```

Return Value:

Error code	Value	Description
E_SUCCESS	0	Normal
E_INVALID_PARAMETER	-1	Invalid parameter
E_INVALID_MODEL_TYPE	-3	This model does not support this feature.
E_BAD_HANDLE	-6	Invalid handle
E_IO_PORT_NOT_OPEN	-309	Communication port not open
E_IO_WRITE_FAILED	-321	Write failed
E_IO_WRITE_TIMEOUT	-322	Write timeout

4.32 ZPL_PrintImage

This function is to print image.

```
int ZPL_PrintImage(
```

```
    void* handle,
```

```
    int xPos,
```

```
    int yPos,
```

```
    char* imgName
```

```
);
```

parameter:

```
void* handle
```

[in,out] The created target printer object.

```
int xPos
```

[in] Horizontal starting position (range: 0-32000).

```
int yPos
```

[in] Vertical starting position (range: 0-32000).

```
char* imgName
```

[in] The path to the image.

Return Value:

Error code	Value	Description
E_SUCCESS	0	Normal
E_INVALID_PARAMETER	-1	Invalid parameter
E_INVALID_MODEL_TYPE	-3	This model does not support this feature.
E_BAD_HANDLE	-6	Invalid handle
E_IO_PORT_NOT_OPEN	-309	Communication port not open
E_IO_WRITE_FAILED	-321	Write failed
E_IO_WRITE_TIMEOUT	-322	Write timeout

4.33 ZPL_GraphicSymbol

This function is to generate registered trademarks, copyright symbols and other symbols.

```
int ZPL_GraphicSymbol(  
    void* handle,  
    int xPos,  
    int yPos,  
    int orientation,  
    int width,  
    int height,  
    char* type  
) ;
```

Parameter:

```
void* handle  
    [in,out] The created target printer object.  
int xPos  
    [in] Horizontal starting position (range: 0-32000).  
int yPos  
    [in] Vertical starting position (range: 0-32000).  
int orientation  
    [in] Print direction.  
        0 : normal  
        90 : Rotate 90 degrees clockwise  
        180: Rotate 180 degrees clockwise  
        270: Rotate 270 degrees clockwise  
int width  
    [in] Symbol width.  
int height  
    [in] Symbol height.
```

char type*

[in] Data string.

Return Value:

Error Code	Value	Description
E_SUCCESS	0	Normal
E_INVALID_PARAMETER	-1	Invalid parameter
E_BAD_HANDLE	-6	Invalid handle
E_IO_PORT_NOT_OPEN	-309	Communication port not open
E_IO_WRITE_FAILED	-321	Write failed
E_IO_WRITE_TIMEOUT	-322	Write timeout

4.34 ZPL_SetDiagnosticsMode

This function is to start the diagnostic mode.

```
int ZPL_SetDiagnosticsMode(  
    void* handle,  
    int isEnabled  
) ;
```

Parameter:

void handle*
[in,out] The created target printer object.
int isEnabled
[in] Whether to enable the diagnostic mode.
1 : Turn on diagnostic mode
0 : Cancel diagnostic mode

Return Value:

Error code	Value	Description
E_SUCCESS	0	Normal
E_INVALID_PARAMETER	-1	Invalid parameter
E_INVALID_MODEL_TYPE	-3	This model does not support this feature.
E_BAD_HANDLE	-6	Invalid handle
E_IO_PORT_NOT_OPEN	-309	Communication port not open
E_IO_WRITE_FAILED	-321	Write failed
E_IO_WRITE_TIMEOUT	-322	Write timeout

4.35 ZPL_SetLabelHome

This function is to set the label home position.

```
int ZPL_SetLabelHome(  
    void* handle  
    int xPos,  
    int yPos  
)
```

Parameter:

void handle*
[in,out] The created target printer object.
int xPos
[in] Horizontal starting position (range: 0-32000).
int yPos
[in] Vertical starting position (range: 0-32000).

Return Value:

Error code	Value	Description
E_SUCCESS	0	Normal
E_INVALID_PARAMETER	-1	Invalid parameter
E_INVALID_MODEL_TYPE	-3	This model does not support this feature.
E_BAD_HANDLE	-6	Invalid handle
E_IO_PORT_NOT_OPEN	-309	Communication port not open
E_IO_WRITE_FAILED	-321	Write failed
E_IO_WRITE_TIMEOUT	-322	Write timeout

4.36 ZPL_SetLabelLength

This function is to set the label length.

```
int ZPL_SetLabelLength(  
    void* handle,  
    int length  
)
```

Parameter:

void handle*
[in,out] The created target printer object.
int length
[in] Label length (range: 1-32000, unit: dot).

Return Value:

Error code	Value	Description
E_SUCCESS	0	Normal
E_INVALID_PARAMETER	-1	Invalid parameter
E_INVALID_MODEL_TYPE	-3	This model does not support this feature.
E_BAD_HANDLE	-6	Invalid handle
E_IO_PORT_NOT_OPEN	-309	Communication port not open
E_IO_WRITE_FAILED	-321	Write failed
E_IO_WRITE_TIMEOUT	-322	Write timeout

4.37 ZPL_SetLabelShift

This function is to move the contents of the label to the left.

```
int ZPL_SetLabelShift(  
    void* handle,  
    int shift  
) ;
```

Parameter:

void handle*

[in,out] The created target printer object.

int shift

[in] The value to move to the left (range: -9999–9999, unit: dot).

Return Value:

Error code	Value	Description
E_SUCCESS	0	Normal
E_INVALID_PARAMETER	-1	Invalid parameter
E_INVALID_MODEL_TYPE	-3	This model does not support this feature.
E_BAD_HANDLE	-6	Invalid handle
E_IO_PORT_NOT_OPEN	-309	Communication port not open
E_IO_WRITE_FAILED	-321	Write failed
E_IO_WRITE_TIMEOUT	-322	Write timeout

4.38 ZPL_SetLabelTop

This function is to move the position of the label up or down a short distance relative to the top edge of the label.

```
int ZPL_SetLabelTop(  
    void* handle,  
    int top  
)
```

Parameter:

void handle*
[in,out] The created target printer object.
int top
[in] Maximum degree (range: -120–120, unit: dot).

Return Value:

Error code	Value	Description
E_SUCCESS	0	Normal
E_INVALID_PARAMETER	-1	Invalid parameter
E_INVALID_MODEL_TYPE	-3	This model does not support this feature.
E_BAD_HANDLE	-6	Invalid handle
E_IO_PORT_NOT_OPEN	-309	Communication port not open
E_IO_WRITE_FAILED	-321	Write failed
E_IO_WRITE_TIMEOUT	-322	Write timeout

4.39 ZPL_SetPrintMode

This function is to set the action the printer performs after printing a label or label group.

```
int ZPL_SetPrintMode(  
    void* handle,  
    char mode,  
    char prePeelSelect  
) ;
```

Parameter:

void handle*
[in,out] The created target printer object.
char mode
[in] Operating mode.
'T': tear open
'P': stripping (not available on S-300)
'R': rewind (depending on the printer model)
'A': applicator (depending on printer model)
'C': cutter (depending on printer model)
'D': cutter delay
'F': RFID
'L': reserved
'U': reserved
'K': Kiosk
char prePeelSelect
[in] select.
'N': not execute
'Y': execute

Return Value:

Error code	Value	Description
E_SUCCESS	0	Normal
E_INVALID_PARAMETER	-1	Invalid parameter
E_INVALID_MODEL_TYPE	-3	This model does not support this feature.
E_BAD_HANDLE	-6	Invalid handle
E_IO_PORT_NOT_OPEN	-309	Communication port not open
E_IO_WRITE_FAILED	-321	Write failed
E_IO_WRITE_TIMEOUT	-322	Write timeout

4.40 ZPL_SetMediaType

This function is to select the type of media used in the printer.

```
int ZPL_SetMediaType(  
    void* handle,  
    char type  
) ;
```

Parameter:

void handle*
[in,out] The created target printer object.
char type
[in] Media type.
‘T’ : thermal transfer media
‘D’ : direct thermal media

Return Value:

Error code	Value	Description
E_SUCCESS	0	Normal
E_INVALID_PARAMETER	-1	Invalid parameter
E_INVALID_MODEL_TYPE	-3	This model does not support this feature.
E_BAD_HANDLE	-6	Invalid handle
E_IO_PORT_NOT_OPEN	-309	Communication port not open
E_IO_WRITE_FAILED	-321	Write failed
E_IO_WRITE_TIMEOUT	-322	Write timeout

4.41 ZPL_SetPrintingMirrorImage

This function is to print the entire printable area of the label as a mirror image.

```
int ZPL_SetPrintingMirrorImage(  
    void* handle,  
    char enable  
) ;
```

Parameter:

void handle*
[in,out] The created target printer object.
char enable
[in] Whether to open.
‘N’: not open
‘Y’: open

Return Value:

Error code	Value	Description
E_SUCCESS	0	Normal
E_INVALID_PARAMETER	-1	Invalid parameter
E_INVALID_MODEL_TYPE	-3	This model does not support this feature.
E_BAD_HANDLE	-6	Invalid handle
E_IO_PORT_NOT_OPEN	-309	Communication port not open
E_IO_WRITE_FAILED	-321	Write failed
E_IO_WRITE_TIMEOUT	-322	Write timeout

4.42 ZPL_SetPrintOrientation

This function is to flip the label format 180 degrees.

```
int ZPL_SetPrintOrientation(  
    void* handle,  
    int orientation  
) ;
```

Parameter:

void handle*
[in,out] The created target printer object.
int orientation
[in] Whether to flip.
0: don't flip
180: perform a flip

Return Value:

Error code	Value	Description
E_SUCCESS	0	Normal
E_INVALID_PARAMETER	-1	Invalid parameter
E_INVALID_MODEL_TYPE	-3	This model does not support this feature.
E_BAD_HANDLE	-6	Invalid handle
E_IO_PORT_NOT_OPEN	-309	Communication port not open
E_IO_WRITE_FAILED	-321	Write failed
E_IO_WRITE_TIMEOUT	-322	Write timeout

4.43 ZPL_SetPrintRate

This function is to set the print speed.

```
int ZPL_SetPrintRate(  
    void* handle,  
    int printSpeed,  
    int slewSpeed,  
    int backfeedSpeed  
) ;
```

Parameter:

```
void* handle  
    [in,out] The created target printer object.  
int printSpeed  
    [in] Print speed.  
int slewSpeed  
    [in] Swing speed.  
int backfeedSpeed  
    [in] Feedback speed.
```

Return Value:

Error code	Value	Description
E_SUCCESS	0	Normal
E_INVALID_PARAMETER	-1	Invalid parameter
E_INVALID_MODEL_TYPE	-3	This model does not support this feature.
E_BAD_HANDLE	-6	Invalid handle
E_IO_PORT_NOT_OPEN	-309	Communication port not open
E_IO_WRITE_FAILED	-321	Write failed
E_IO_WRITE_TIMEOUT	-322	Write timeout

4.44 ZPL_SetPrintWidth

This function is to set print width.

```
int ZPL_SetPrintWidth(  
    void* handle,  
    int width  
)
```

Parameter:

void handle*
[in,out] The created target printer object.
int width
[in] Set the print width (range: 2-944, unit: dot).

Return Value:

Error code	Value	Description
E_SUCCESS	0	Normal
E_INVALID_PARAMETER	-1	Invalid parameter
E_INVALID_MODEL_TYPE	-3	This model does not support this feature.
E_BAD_HANDLE	-6	Invalid handle
E_IO_PORT_NOT_OPEN	-309	Communication port not open
E_IO_WRITE_FAILED	-321	Write failed
E_IO_WRITE_TIMEOUT	-322	Write timeout

4.45 ZPL_SetSerialCommunications

This function is to change the serial communication parameters.

```
int ZPL_SetSerialCommunications(  
    void* handle,  
    int baudRate,  
    int wordLength,  
    char parity,  
    int stopBits,  
    char protocolModo,  
    char zebraProtocol  
) ;
```

Parameter:

void handle*
[in,out] The created target printer object.
int baudRate

[in] Bandwidth frequency. The scope is as follows:

110	300	600	1200	2400
4800	9600	14400	19200	28800
38400	57600	115200		

int wordLength
[in] Word length: 7-8, unit: data bits.

char parity
[in] as follows:
'N': means: none.
'E': means: even.
'O': means: odd.

int stopBits
[in] Range: 1-2.

char protocolModo

[in] as follows:

'X': indicates: XON/XOFF.

'D': indicates: DTR/DSR.

'R': indicates: RTS.

'M': indicates: DTR/DSR XON/XOFF r.

char zebraProtocol

[in] as follows:

'A': indicates: ACK/NAK.

'N': means: None.

'Z': indicates: Zebra.

Return Value:

Error code	Value	Description
E_SUCCESS	0	Normal
E_INVALID_PARAMETER	-1	Invalid parameter
E_INVALID_MODEL_TYPE	-3	This model does not support this feature.
E_BAD_HANDLE	-6	Invalid handle
E_IO_PORT_NOT_OPEN	-309	Communication port not open
E_IO_WRITE_FAILED	-321	Write failed
E_IO_WRITE_TIMEOUT	-322	Write timeout

4.46 ZPL_SetPrintDarkness

This function is to set print darkness.

```
int ZPL_SetPrintDarkness (
    void* handle,
    int darkness
);
```

Parameter:

void handle*
[in,out] The created target printer object.
int darkness
[in] Print darkness(Range: 0-30, unit: dot).

Return Value:

Error code	Value	Description
E_SUCCESS	0	Normal
E_INVALID_PARAMETER	-1	Invalid parameter
E_INVALID_MODEL_TYPE	-3	This model does not support this feature.
E_BAD_HANDLE	-6	Invalid handle
E_IO_PORT_NOT_OPEN	-309	Communication port not open
E_IO_WRITE_FAILED	-321	Write failed
E_IO_WRITE_TIMEOUT	-322	Write timeout

4.47 ZPL_SetTearOffAdjustPosition

This function is to set the position where the label is torn away.

```
int ZPL_SetTearOffAdjustPosition (
    void* handle,
    int position
);
```

Parameter:

void handle*
[in,out] The created target printer object.
int position
[in] Peel off position (range: 0-120).

Return Value:

Error code	Value	Description
E_SUCCESS	0	Normal
E_INVALID_PARAMETER	-1	Invalid parameter
E_INVALID_MODEL_TYPE	-3	This model does not support this feature.
E_BAD_HANDLE	-6	Invalid handle
E_IO_PORT_NOT_OPEN	-309	Communication port not open
E_IO_WRITE_FAILED	-321	Write failed
E_IO_WRITE_TIMEOUT	-322	Write timeout

4.48 ZPL_PrintConfigurationLabel

This function is to generate a printer configuration label.

```
int ZPL_PrintConfigurationLabel(  
    void* handle  
)
```

Parameter:

void handle*
[in,out] The created target printer object.

Return Value:

Error code	Value	Description
E_SUCCESS	0	Normal
E_INVALID_PARAMETER	-1	Invalid parameter
E_INVALID_MODEL_TYPE	-3	This model does not support this feature.
E_BAD_HANDLE	-6	Invalid handle
E_IO_PORT_NOT_OPEN	-309	Communication port not open
E_IO_WRITE_FAILED	-321	Write failed
E_IO_WRITE_TIMEOUT	-322	Write timeout

4.49 ZPL_GetPrinterIpAddress

This function is to get the printer IP address.

```
int ZPL_GetPrinterIpAddress(  
    void* handle  
    char* ipAddress  
)
```

Parameter:

```
void* handle  
    [in,out] The created target printer object.  
char* ipAddress  
    [in] Printer's IP address.
```

Return Value:

Error code	Value	Description
E_SUCCESS	0	Normal
E_INVALID_PARAMETER	-1	Invalid parameter
E_INVALID_MODEL_TYPE	-3	This model does not support this feature.
E_BAD_HANDLE	-6	Invalid handle
E_IO_PORT_NOT_OPEN	-309	Communication port not open
E_IO_WRITE_FAILED	-321	Write failed
E_IO_WRITE_TIMEOUT	-322	Write timeout

4.50 ZPL_GetPrinterStatus

This function is to get the status of the printer.

```
int ZPL_GetPrinterStatus (
    void* handle,
    int* status
);
```

Parameter:

void handle*
[in,out] The created target printer object.
int status*
[in] The status of the printer.

Return Value:

Error code	Value	Description
E_SUCCESS	0	Normal
E_INVALID_PARAMETER	-1	Invalid parameter
E_INVALID_MODEL_TYPE	-3	This model does not support this feature.
E_BAD_HANDLE	-6	Invalid handle
E_IO_PORT_NOT_OPEN	-309	Communication port not open
E_IO_WRITE_FAILED	-321	Write failed
E_IO_WRITE_TIMEOUT	-322	Write timeout

4.51 ZPL_GetLabelLength

This function is to get the length of the label.

```
int ZPL_GetLabelLength (
    void* handle,
    char* length
);
```

Parameter:

void handle*
[in,out] The created target printer object.
char length*
[in] The length of the label.

Return Value:

Error code	Value	Description
E_SUCCESS	0	Normal
E_INVALID_PARAMETER	-1	Invalid parameter
E_INVALID_MODEL_TYPE	-3	This model does not support this feature.
E_BAD_HANDLE	-6	Invalid handle
E_IO_PORT_NOT_OPEN	-309	Communication port not open
E_IO_WRITE_FAILED	-321	Write failed
E_IO_WRITE_TIMEOUT	-322	Write timeout

4.52 ZPL_GetLabelWidth

This function is to get the width of the label.

```
int ZPL_GetLabelWidth(  
    void* handle,  
    char* width  
) ;
```

Parameter:

void handle*
[in,out] The created target printer object.
char width*
[in] The width of the label.

Return Value:

Error code	Value	Description
E_SUCCESS	0	Normal
E_INVALID_PARAMETER	-1	Invalid parameter
E_INVALID_MODEL_TYPE	-3	This model does not support this feature.
E_BAD_HANDLE	-6	Invalid handle
E_IO_PORT_NOT_OPEN	-309	Communication port not open
E_IO_WRITE_FAILED	-321	Write failed
E_IO_WRITE_TIMEOUT	-322	Write timeout

4.53 ZPL_GetPrinterSeriesNumber

This function is to get the printer serial number.

```
int ZPL_GetPrinterSeriesNumber(  
    void* handle,  
    char* sn  
) ;
```

Parameter:

void handle*
[in,out] The created target printer object.
char sn*
[in] Printer serial number.

Return Value:

Error code	Value	Description
E_SUCCESS	0	Normal
E_INVALID_PARAMETER	-1	Invalid parameter
E_INVALID_MODEL_TYPE	-3	This model does not support this feature.
E_BAD_HANDLE	-6	Invalid handle
E_IO_PORT_NOT_OPEN	-309	Communication port not open
E_IO_WRITE_FAILED	-321	Write failed
E_IO_WRITE_TIMEOUT	-322	Write timeout

4.54 ZPL_GetPrinterMacAddress

This function is to get the printer's MAC address.

```
int ZPL_GetPrinterMacAddress(  
    void* handle,  
    char* macAddressss  
) ;
```

Parameter:

void handle*
[in,out] The created target printer object.
char macAddress*
[in] The MAC address of the printer.

Return Value:

Error code	Value	Description
E_SUCCESS	0	Normal
E_INVALID_PARAMETER	-1	Invalid parameter
E_INVALID_MODEL_TYPE	-3	This model does not support this feature.
E_BAD_HANDLE	-6	Invalid handle
E_IO_PORT_NOT_OPEN	-309	Communication port not open
E_IO_WRITE_FAILED	-321	Write failed
E_IO_WRITE_TIMEOUT	-322	Write timeout

4.55 ZPL_GetPrinterName

This function is to get the printer's name.

```
int ZPL_GetPrinterName(  
    void* handle,  
    char* name  
) ;
```

Parameter:

void handle*
[in,out] The created target printer object.
char name*
[in] The name of the printer.

Return Value:

Error code	Value	Description
E_SUCCESS	0	Normal
E_INVALID_PARAMETER	-1	Invalid parameter
E_INVALID_MODEL_TYPE	-3	This model does not support this feature.
E_BAD_HANDLE	-6	Invalid handle
E_IO_PORT_NOT_OPEN	-309	Communication port not open
E_IO_WRITE_FAILED	-321	Write failed
E_IO_WRITE_TIMEOUT	-322	Write timeout

4.56 ZPL_GetPrinterFirmwareVersion

This function is to get the firmware version number of the printer.

```
int ZPL_GetPrinterFirmwareVersion(  
    void* handle,  
    char* version  
) ;
```

Parameter:

void handle*
[in,out] The created target printer object.
char version*
[in] The firmware version number of the printer.

Return Value:

Error code	Value	Description
E_SUCCESS	0	Normal
E_INVALID_PARAMETER	-1	Invalid parameter
E_INVALID_MODEL_TYPE	-3	This model does not support this feature.
E_BAD_HANDLE	-6	Invalid handle
E_IO_PORT_NOT_OPEN	-309	Communication port not open
E_IO_WRITE_FAILED	-321	Write failed
E_IO_WRITE_TIMEOUT	-322	Write timeout

4.57 ZPL_GetPrinterDpi

This function is to get the resolution of the printer.

```
int ZPL_GetPrinterDpi(  
    void* handle,  
    char* dpi  
) ;
```

Parameter:

void handle*
[in,out] The created target printer object.
char dpi*
[in] The resolution of the printer.

Return Value:

Error code	Value	Description
E_SUCCESS	0	Normal
E_INVALID_PARAMETER	-1	Invalid parameter
E_INVALID_MODEL_TYPE	-3	This model does not support this feature.
E_BAD_HANDLE	-6	Invalid handle
E_IO_PORT_NOT_OPEN	-309	Communication port not open
E_IO_WRITE_FAILED	-321	Write failed
E_IO_WRITE_TIMEOUT	-322	Write timeout

4.58 ZPL_LearnLabel

This function is to automatically recognize the length of the label.

```
int ZPL_LearnLabel(  
    void* handle,  
);
```

Parameter:

void handle*
[in,out] The created target printer object.

Return Value:

Error code	Value	Description
E_SUCCESS	0	Normal
E_INVALID_PARAMETER	-1	Invalid parameter
E_INVALID_MODEL_TYPE	-3	This model does not support this feature.
E_BAD_HANDLE	-6	Invalid handle
E_IO_PORT_NOT_OPEN	-309	Communication port not open
E_IO_WRITE_FAILED	-321	Write failed
E_IO_WRITE_TIMEOUT	-322	Write timeout

4.59 ZPL_SetReprintAfterError

This function is to reprint the labels that failed to print due to an error (error conditions include Ribbon Out, Media Out, Head Open).

```
int ZPL_SetReprintAfterError(  
    void* handle,  
    char enable  
) ;
```

Parameter:

void handle*
[in,out] The created target printer object.
char enable
[in] Whether to reprint.
'N': not reprint
'Y': Perform reprint

Return Value:

Error code	Value	Description
E_SUCCESS	0	Normal
E_INVALID_PARAMETER	-1	Invalid parameter
E_INVALID_MODEL_TYPE	-3	This model does not support this feature.
E_BAD_HANDLE	-6	Invalid handle
E_IO_PORT_NOT_OPEN	-309	Communication port not open
E_IO_WRITE_FAILED	-321	Write failed
E_IO_WRITE_TIMEOUT	-322	Write timeout

4.60 ZPL_SetNetworkSetting

This function is to change the network settings on the printer.

```
int ZPL_SetNetworkSetting(  
    void* handle,  
    char* network  
) ;
```

Parameter:

void handle*
[in,out] The created target printer object.
char network*
[in] Format “a,b,c,d,e,f,g,h,i,j”
a position (the device that is being modified):
 1 express: external wired;
 2 express: internal wired;
 3 express: wireless;
b position (IP resolution):
 A express: All;
 B express: BOOTP;
 C express: DHCP and BOOTP;
 D express: DHCP;
 G express: Gleaning only (Not recommended when the Wireless Print Server
 or Wireless Plus Print Server is installed.);
 R express: RARP;
 P express: Permanent;
c position (IP address) : format: xxx.xxx.xxx.xxx
d position (subnet mask) : format: xxx.xxx.xxx.xxx
e position (default gateway) : format: xxx.xxx.xxx.xxx
f position (WINS server address) : format: xxx.xxx.xxx.xxx
g position (connection timeout checking) : Whether timeout detection: Y=yes, N=no
h position (timeout value) : range: 0-9999.
i position (ARP broadcast interval) :range: 0-30.
j position (ARP broadcast interval) :range: 1-65535.

Parameter setting example: “1, A, 192.168.1.1, 255.255.255.0, 192.168.1.1, 192.168.1.1,
Y, 300, 0, 9100”

Return Value:

Error code	Value	Description
E_SUCCESS	0	Normal
E_INVALID_PARAMETER	-1	Invalid parameter
E_INVALID_MODEL_TYPE	-3	This model does not support this feature.
E_BAD_HANDLE	-6	Invalid handle
E_IO_PORT_NOT_OPEN	-309	Communication port not open
E_IO_WRITE_FAILED	-321	Write failed
E_IO_WRITE_TIMEOUT	-322	Write timeout

4.61 ZPL_SetMediaTracking

This function is to specify the media type being used and the black mark offset.

```
int ZPL_SetMediaTracking(  
    void* handle,  
    char mediaType,  
    int offset  
)
```

Parameter:

void handle*

[in,out] The created target printer object.

char mediaType

[in] Media Type.

'N': continuous media(continuous paper)

'Y': non-continuous media web sensing(label paper)

'W': non-continuous media web sensing(label paper)

'M': non-continuous media mark sensing(black mark paper)

'A': auto-detects the type of media during calibration

'V': continuous media, variable length(Same as continuum, but if the portion of the printed label exceeds the defined label length, the label size will automatically expand to include them)

int offset

[in] Black mark offset (unused, set to 0) .

Return Value:

Error code	Value	Description
E_SUCCESS	0	Normal
E_INVALID_PARAMETER	-1	Invalid parameter
E_INVALID_MODEL_TYPE	-3	This model does not support this feature.
E_BAD_HANDLE	-6	Invalid handle
E_IO_PORT_NOT_OPEN	-309	Communication port not open
E_IO_WRITE_FAILED	-321	Write failed
E_IO_WRITE_TIMEOUT	-322	Write timeout